



Play | Outer-casing (frameless)



99754

Play System Recessed Casing with particular threading to screw onto the edge of the false ceiling. Driver, secondary cabling and assembly brackets included.

Play | Outer-casing (with frame)



White



99752

Black

99753

Play System Recessed Casing with spring flange for flush installation on the false ceiling. Driver and secondary cabling included.

Play | Closing cap



White

99755

Black

99756

Recessed casing closing plug in case of the absence of Play System article. Only mechanical fixing, not electrical connection.