




**Tee | Fixing accessory with springs for recessed installation**




White	<b>98972</b>
Black	<b>98973</b>
Chrome	<b>98974</b>
Nickel	<b>98975</b>

**Tee | Accessory with threaded pin for recessed installation**




White	<b>98980</b>
Black	<b>98981</b>
Chrome	<b>98982</b>
Nickel	<b>98983</b>

**Tee\_1 & Tee\_2 | Accessory with fixing screws for surface installation**



White	<b>98976</b>
Black	<b>98977</b>
Chrome	<b>98978</b>
Nickel	<b>98979</b>

**Tee\_1 & Tee\_2 | Driver-holder base for ceiling-mounted installation (driver excluded)**



White	<b>99503</b>
Black	<b>99504</b>
Chrome	<b>99505</b>
Nickel	<b>99506</b>

Tee\_1 driver



**89148**  
ON/OFF  
1 - 2 art.  
For base

Tee\_2 driver



**89151**  
ON/OFF  
1 - 2 art.  
For base